




EPT12-EZ

Electric Hand Pallet Truck

Parts Manual

电动搬运车 零件目录



PARTS ORDERING INSTRUCTIONS

HOW TO ORDER

When you order, supply the part number, quantity, model and serial numbers of your machine. Supplying this information will assure prompt, efficient handling of your order. Since your dealer carries many parts in stock and maintains up-to-date prices on all parts, he will be able to process your order immediately. If, for some reason, the part is not in stock, he will order it from the factory. In either event, he maintains a current file of service manuals, which give all available parts ordering or technical information.

WHERE TO ORDER

Always order parts from the dealer who sold you your truck. If it is necessary for the dealer to order parts from the factory, he is able to get prompt service for you. Parts are shipped in accordance with shipping instructions given on the order.

INSTRUCTIONS FOR RETURNING PARTS

Under NO CIRCUMSTANCES will parts be accepted at the factory for credit without prior approval. We cannot accept responsibility for parts returned without authorization. If you have some parts which must be returned, contact your dealer. If he believes parts should be returned, he will arrange for authorization to return the parts.

CHANGES

When changes are made to the machine, revised pages for this manual will be issued. These pages must be inserted in your parts manual as soon as they are received. Failure to keep your parts manuals up to date will result in confusion and may cause you to order wrong parts.

EP EQUIPMENT CO.,LTD.

Address: XIAQUAN,DIPU,ANJI,ZHEJIANG,CHINA

Tel:86-571-28035626/28035657

Fax:86-571-28035616

Net: www.ep-ep.com

Email:epparts@ep-ep.com

ALL RIGHT RESERVED COPYRIGHT

PM1113 01.19

零件订购说明

如何订购

当您订购的时候，您需要提供搬运车零件的编号，数量，型号和序列号。提供这些信息能够保证您的订购更加的高效。

因为您的经销商有很多零件的存货，而且需要保持所有零件的价格是最新的，所以他会尽快地处理您的订购需求。假如因为某些原因，存货中没有这个零件，那么他会从公司订货。无论怎么样的情况，他手里都会有一份服务手册文件，它能提供所有可用的零件的订购信息或者技术信息。

订购地点

当您需要订购零件时，请到销售给您搬运车的经销商那里订购。如果经销商有必要从公司订购零件，他能为您提供快捷的服务。根据您的订购信息，零件和它对应的操作说明会一起装好。

零件的退还说明

一般情况下，因为信用的关系，退还的零件没有事先的同意，是不会被公司认可的。我们不会对没有经过授权但退还过来的零件负责。

如果您有一些零件一定要退还，请联系您的经销商。若经销商确认零件可以退还，则其会安排授权要退还的零件。

技术修改

当搬运车技术有修改时，这本手册的修正页会重新发行。当您拿到这些修正页时，您一定要立即把它们插入到您的零件手册中。若没有及时的更新您的零件手册，则可能会导致您订购、维护等方面的错误。

浙江中力机械有限公司

地址：浙江省安吉县递铺镇霞泉村中力园区

电话：86-571-28027600/28035663

传真：86-571-28035616

网址：www.ep-ep.com

邮箱：epparts@ep-ep.com

版权归本公司所有

GENERAL INFORMATION

INDEX

This parts manual is arranged for easy identification of parts .The index at the front of the catalog gives location of major groups and assemblies.

PART LIST

The Index, describes the item on the Figure you are looking at. The Part No. is a numerical description of the item and the part ordering number. The Part Name is a description of the part number in alphabetical form. The No.is the quantity used on the machine. The Applied Date is a description when the part is applicable.The Remark is the explanation of the part for a supplement such as the model the capability, the characteristic etc.

HOW TO READ PARTS MANUAL

HELP 1:

	Index	Part No.	Part Name	No.	Applied Date	Remark
A 	9	1120-342101-00	Button Bracket (L)	1		
	10	1120-342002-00	Horn Button	1		
		1120-342005-00	Pin	2		
		1120-342003-00	Spring	2		
		1120-342004-00	Button Bracket	1		
	11	0000-000039-00	Screw ST3.5×9.5	6		
B 	22	2108-540000-00	Bracket	1		
	23	2108-550000-00-01	Battery	2		60AH / 12V
	23	2108-550000-00-02	Battery	2		80AH / 12V
	24	0000-000378-00	Screw M4×16	2		

A: The part of Index 19 is a discreteness with two kinds of parts.It denotes **Not Sold Separately**.

B: The part of Index 23 is Optional.

	Index	Part No.	Part Name	No.	Applied Date	Remark
C ➡	8	Ck11-560003-00	Jc100 Switch	1		
	9 01	Ck11-520008-00	JC100 Switch Wire Harness	1		
	02	Ck11-520008-00	JC100 Switch Wire Harness	1		Superseded
	10	0000-000001-00	Screw M6X20	2		
D ➡	7 01	2125-410004-00	Cap	1		-071011
	02	2125-410004-0A	Cap	1	071011-	
	8	2108-550000-00	Battery	2		
	9	0000-000378-00	Screw M4×16	2		
	10	2125-410005-00	Ring Back Up 50X45X6	1		
	11 01	0000-000197-00	Ring Packig 40X50X6	1		Old
	02	0000-000512-00	Ring Packig 40X50X6	1		New

C: The part of index 9 is improved and upgraded. Please use the **New Part Number** when ordering.

D: The part of Index 7 has an **Applicability**, because it's our policy to constantly improve our products.

The part of Index 11 is same but the Part Number is changed. And please use the new Part Number when you order this part.

1. Record by time

- **070911** : Ending on July 09, 2011.

071011- : Beginning on July 10, 2011.

2. Record by serial number

	Index	Part No.	Part Name	No.	Applied Date	Remark
D ➡	7 01	2125-410004-00	Cap	1		-S2016344
	02	2125-410004-0A	Cap	1	S2016345-	
	8	2108-550000-00	Battery	2		
	9	0000-000378-00	Screw M4×16	2		
	10	2125-410005-00	Ring Back Up 50X45X6	1		
	11 01	0000-000197-00	Ring Packig 40X50X6	1		Old
	02	0000-000512-00	Ring Packig 40X50X6	1		New


-**S2016344** : Ending at S2016344

S2016345- : Starting at S2016345

There are three types of serial number:


1) 1 (LETTER)+7 (NUMBERS)

Applied Date: Up to February 1,2015




3) 1 (NUMBER)+ 8 (NUMBERS)

Applied Date: From June 1,2015




2) 1 (LETTER)+ 8 (NUMBERS)

Applied Date: From February 1,2015 to June 1,2015



HELP 2:



A:Section 0101 is the original version.

B:Section 010101 is the version that some parts in the Section 0503 have been changed.

C:Section 010102 is the version that some parts in the Section 050301 have been changed.

When you order, Please locate specific parts information of your truck by the Applied Date of parts in each version.

概要

目录

将零件目录分组成几个易识别的部分，并把主要结构和总成放置在索引目录中。

零件明细表

Index 描述的是在插图上，您想要找的项目。**Part No.**是零件的一系列描述和它的订购号码。**Part Name** 是用文字的形式描述零件的号码。**No.**代表的是零件在搬运车上使用的数量。**Applied Date** 表示的是零件适用的时间范围。**Remark** 是用来补充说明零件信息(例如车型、性能和特征等)。

怎么读取零件明目录

帮助 1:

	Index	Part No.	Part Name	No.	Applied Date	Remark
	序号	零件编号	零件名称	数量	适用日期	备注
A 	18	0000-000667-00	Bearing 61905Z	轴承	1	
	19	1115-200004-00	Helical Gear	大斜齿	1	
		1115-200005-00	Helical Gear	小斜齿	1	
	20	0000-000680-00	Bearing 16003Z	轴承	1	
B 	22	2108-540000-00	Bracket	电瓶固定板	1	
	23	1115-500005-00-01	Battery	电瓶	2	65AH / 12V
	23	1115-500005-00-02	Battery	电瓶	2	85AH / 12V
	24	0000-000378-00	Screw M4×16	螺钉	2	
C 	8	ck11-560003-00	JC100 Switch	拇指开关	1	
	9	01 ck11-520008-00	JC100 Switch Wire Harness	JC100 线束	1	Cancelled/取消
		02 ck11-520008-0A	JC100 Switch Wire Harness	JC100 线束	1	
	10	0000-000001-00	Screw M6×20	螺钉	2	

A: 序号 19 表示的是一个由两种零件组成的组件，不以单件形式出售。

B: 序号 23 表示该零件有几个品种可供您的选择。

C: 序号 9 表示该零件进行了改进和升级，订购时请使用新的零件编码。

D: 序号 7 表示该零件有一个适用的时间范围。这是因为我们在不断地进行产品的升级。

序号 11 表示的都是同一种零件，只是零件编码有所变更。因此，当您订购这类零件时，请您使用新的零件编码。

Index 序号	Part No. 零件编号	Part Name 零件名称	No. 数量	Applied Date 适用日期	Remark 备注
7 01	2125-410004-00	Cap 导向套	1	-071011	
02	2125-410004-0A	Cap 导向套	1	071011-	
8	0000-000084-00	Ring Wiper 35×43×5-6.5 防尘圈	1		
9	0000-000370-00	O-ring 40×3.1 O 型密封圈	1		
10	2125-410005-00	Ring Back Up 50×45×20 支撑环	1		
11 01	0000-000197-00	Rod Packing 40×50×6 Yx 密封圈	1		Old
02	0000-000512-00	Rod Packing 40×50×6 Yx 密封圈	1		New

1. 用时间记录

- 070911 : 截止到 2011 年 7 月 09 日

071011- : 起始于 2011 年 7 月 10 日

2. 用序列号记录

Index 序号	Part No. 零件编号	Part Name 零件名称	No. 数量	Applied Date 适用日期	Remark 备注
7 01	2125-410004-00	Cap 导向套	1	-S2016344	
02	2125-410004-0A	Cap 导向套	1	S2016345-	
8	0000-000084-00	Ring Wiper 35×43×5-6.5 防尘圈	1		
9	0000-000370-00	O-ring 40×3.1 O 型密封圈	1		
10	2125-410005-00	Ring Back Up 50×45×20 支撑环	1		
11 01	0000-000197-00	Rod Packing 40×50×6 Yx 密封圈	1		Old
02	0000-000512-00	Rod Packing 40×50×6 Yx 密封圈	1		New


-S2016344 : 截止序列号 S2016344

S2016345- : 起始序列号 S2016345

有三种序列号形式：


1) 1 (字母) + 7 (数字)

适用时间： 截止到 2015 年 2 月 1 日




2) 1 (字母) + 8 (数字)

适用时间： 2015 年 2 月 1 日至 2015 年 6 月 1 日




3) 1 (数字) + 8 (数字)

适用时间： 2015 年 6 月 1 日至今



帮助 2:




A: 章节 0503 表示原始版本;

B: 章节 050301 表示在原始版本 (章节 0503) 上零件有所变更;

C: 章节 050302 表示在变更版本 (章节 050301) 上零件有所变更。

当您订购零件时, 请根据每个版本中零件的适用时间来判断您所选购车型的零件信息。

Major Assemblies



WARNING: Note that illustrations of assemblies and components may not necessarily conform to the exact installation as they appear on your truck. But this Manual can help you locate specific parts information of your truck.

注意: 表达在零件目录上的总成和结构内容可能不会完全地出现在您的车型上，但是您可以在零件目录中查询到您所选购车型的零件信息。

Index 目录


1000 Frame System 车架系统.....	1
0101 Frame Assembly 车架系统.....	2
010101 Frame Assembly 车架系统.....	5
0102 Cover 外罩.....	9
2000 Driving System 驱动系统.....	11
0201 Driving System 驱动系统.....	12
0202 Driving System (Big driving wheel) 驱动系统 (大驱动)	15
3000 Operating Control System 操作系统.....	19
0301 operating grip (Manual lowering) 操作杆 (手动下降)	20
0302 Handle head assembly (Manual lowering) 手柄头总成 (手动下降)	23
0303 operating grip (Electric lowering) 操作手柄杆 (电动下降)	25
0304 Handle head assembly (Electric lowering) 手柄头总成 (电动下降)	27
4000 Hydraulic System 液压系统.....	29
0401 Hydraulic System (Manual lowering) 液压系统 (手动下降)	30
040101 Hydraulic System (Manual lowering) 液压系统 (手动下降)	33
040102 Hydraulic System (Manual lowering) 液压系统 (手动下降)	36
0402 Hydraulic System (Electric lowering) 液压系统 (电动下降)	39
040201 Hydraulic System (Electric lowering) 液压系统 (电动下降)	42
040202 Hydraulic System (Electric lowering) 液压系统 (电动下降)	45
5000 Electrical System 电气系统.....	48
0501 Electrical Assembly 电气总成.....	49
0502 Wiring Harness 线束.....	52
050201 Wiring Harness 线束.....	54
0503 Cable Assembly 电缆.....	56
0504 Charger Assembly 充电器总成.....	58

1000

Frame System

车架系统

0101 Frame Assembly 车架系统




0101 Frame Assembly 车架系统

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1113-110000-10	Front Frame 车架	1		For 560
1		1113-110000-00	Front Frame 车架	1		For 685
2		0000-001333-00	Round Pin $\varnothing 6 \times 35$ 弹簧销	1		
3		0000-000708-00	Pin $\varnothing 5 \times 35$ 弹簧销	4		
3		0000-000708-00	Pin $\varnothing 5 \times 35$ 弹簧销	2		For Single Wheel
4		1113-130001-10	Long Shaft 长支撑轴	1		For 560
4		1113-130001-00	Long Shaft 长支撑轴	1		For 685
5		1113-130002-00	Short Shaft 短销轴	2		
6		0000-001615-00	Screw M6 $\times$ 20 紧定螺钉	1		
7		1113-144001-10	Cover 前围板	1		For 560
7		1113-144001-00	Cover 前围板	1		For 685
8		0000-001621-00	Screw M8 $\times$ 20 螺钉	2		
9		0000-000172-00	Flatwasher $\varnothing 20$ 平垫	4		For Single Wheel
10		1113-130006-10	Splint 夹板	4		For Double Wheel
11		1113-130006-00	Wheel Bracket 轮架	2		
12		1113-130005-00	Shaft 轮架安装轴	2		
13		0000-000210-00	Flatwasher $\varnothing 8$ 加大平垫	2		
14		0000-000740-00	Nut M8 锁紧螺母	2		
15		0000-001608-00	Screw M8 $\times$ 40 螺钉	2		
16		1113-131000-10	Down Link 下连杆	1		For 560
16		1113-131000-00	Down Link 下连杆	1		For 685
17		1113-130008-00	Bushing 30 $\times$ 25 $\times$ 30 铁基含油轴承	2		
18		1113-130003-00	Shaft 连杆后轴	2		
19		0000-001023-00	Round Pin $\varnothing 4 \times 35$ 弹簧销	4		For Double Wheel
19		0000-001023-00	Round Pin $\varnothing 4 \times 35$ 弹簧销	4		

0101 Frame Assembly 车架系统

Index	Part No.	Part Name	No.	Applied Date	Remark
20	0000-001793-00	Screw M10×10 紧定螺钉	4		
21	1113-132300-00	Thread Head 螺纹头	2		
22	1113-130006-00-B	Single Wheel 单轮	2		For Single Wheel, Pos.3,9,11,27,29,30
22	1113-130006-00-A	Double Wheel 双轮	2		For Double Wheel,Pos.10,11,19,27,28,29,30
23	0000-001629-00	Bushing1615 轴套	4		
24	1113-132200-00	Long Rod 长杆	2		
25	1113-132100-00	Connector 连杆头	2		
26	1113-130004-00	Shaft 连杆前轴	2	-726150340	
27	0000-001742-00	Bushing 1620F 翻边轴套	8		
28	0000-001628-00	Bushing 1812F 翻边轴套	4		For Double Wheel
29	1113-130010-00	Shaft 承载轮连接轴	2		For Single Wheel
29	1115-130007-0A	Shaft 承载轮连接轴	4		For Double Wheel
30	1115-133000-40	Wheel 承载轮	2		For Single Wheel,Pos.34,35
30	1115-133000-00	Wheel 承载轮	4		For Double Wheel,Pos.34,35
31	0000-001704-00	Bolt M4×6 螺栓	2		
32	1113-500013-00	Inductor II 感应片	1		
33	0000-001635-00	Nut 20×1.5 圆螺母	2		
34	1115-133002-40	PU Wheel-Single PU 单轮	2		For Single Wheel
34	1115-133002-00	PU Wheel-Double PU 双轮	4		For Double Wheel
35	0000-000020-00	Bearing 6204 轴承	4		For Single Wheel
35	0000-000020-00	Bearing 6204 轴承	8		For Double Wheel
36	0000-001482-00	Pin4×30 弹簧销	2		
37	0000-000589-00	Retainer Ring Ø16 卡簧	4	-726150340	

010101 Frame Assembly 车架系统



010101 Frame Assembly 车架系统

Index		Part No.	Part Name	No.	Applied Date	Remark
1	01	1113-110000-10	Front Frame 车架	1	-727151069	For 560
	02	1113-110000-1A	Front Frame 车架	1	727151070-	For 560
1	01	1113-110000-00	Front Frame 车架	1	-727151069	For 685
	02	1113-110000-0A	Front Frame 车架	1	727151070-	For 685
2		0000-001333-00	Round Pin ø6×35 弹簧销	1		
3		0000-000708-00	Pin ø5×35 弹簧销	4		
3		0000-000708-00	Pin ø5×35 弹簧销	2		For Single Wheel
4		1113-130001-10	Long Shaft 长支撑轴	1		For 560
4		1113-130001-00	Long Shaft 长支撑轴	1		For 685
5		1113-130002-00	Short Shaft 短销轴	2		
6		0000-001615-00	Screw M6×20 紧定螺钉	1		
7	01	1113-144001-10	Cover 前围板	1	-726211138	For 560
	02	1113-144000-1A	Cover 前围板	1	726211139-	For 560
7	01	1113-144001-10-CK	Cover 前围板	1	-726211138	For 560,CLARK green
	02	1113-144000-1A-CK	Cover 前围板	1	726211139-	For 560,CLARK green
7	01	1113-144001-00	Cover 前围板	1	-727120189	For 685
	02	1113-144000-0A	Cover 前围板	1	727120190-	For 685,EP20181020
7	01	1113-144001-00-CK	Cover 前围板	1	-727120189	For 685,CLARK green
	02	1113-144000-0A-CK	Cover 前围板	1	727120190-	For 685,CLARK green,EP20181020
8		0000-001621-00	Screw M8×20 螺钉	2		
9		0000-000172-00	Flatwasher ø20 平垫	4		For Single Wheel
10		1113-130006-10	Splint 夹板	4		For Double Wheel
11		1113-130006-00	Wheel Bracket 轮架	2		
12		1113-130005-00	Shaft 轮架安装轴	2		
13		0000-000210-00	Flatwasher ø8 加大平垫	2		
14		0000-000740-00	Nut M8 锁紧螺母	4		
15		202800700027	Screw M8×45 螺钉	2		


010101 Frame Assembly 车架系统

Index		Part No.	Part Name	No.	Applied Date	Remark
16		1113-131000-10	Down Link 下连杆	1		For 560, With Bushing
16		1113-131000-00	Down Link 下连杆	1		For 685, With Bushing
17		202800400010	Bolt M8×30 压铆螺栓	2		
18		1113-130003-00	Shaft 连杆后轴	2		
19		0000-001023-00	Round Pin ø4×35 弹簧销	8		For Double Wheel
20		0000-001793-00	Screw M10×10 紧定螺钉	4		
21		1113-132300-00	Thread Head 螺纹头	2		
22		1113-130006-00-B	Single Wheel 单轮	2		For Single Wheel, Pos.3,9,11,27,29,30
22		1113-130006-00-A	Double Wheel 双轮	2		For Double Wheel, Pos.10,11,19,27,28,29,30
23		0000-001629-00	Bushing1615 轴套	2		
24		1113-132200-00	Long Rod 长杆	2		
25		1113-132100-00	Connector 连杆头	2		
26		1113-130004-0A	Shaft 连杆前轴	2	726150341-	
27		0000-001742-00	Bushing 1620F 翻边轴套	4		
28		0000-001628-00	Bushing 1812F 翻边轴套	4		For Double Wheel
29		1113-130010-00	Shaft 承载轮连接轴	2		For Single Wheel
29		1115-130007-0A	Shaft 承载轮连接轴	4		For Double Wheel
30		1115-133000-40	Wheel 承载轮	2		For Single Wheel,Pos.34,35
30		1115-133000-00	Wheel 承载轮	4		For Double Wheel,Pos.34,35
31		0000-001704-00	Bolt M4×6 螺栓	2		
32		1113-500013-00	Inductor II 感应片	1		
33		0000-000561-00	Nut 20×1.5 薄螺母	2		
34		1115-133002-40	PU Wheel-Single PU 单轮	2		For Single Wheel
34		1115-133002-00	PU Wheel-Double PU 双轮	4		For Double Wheel
35		0000-000020-00	Bearing 6204 轴承	4		For Single Wheel
35		0000-000020-00	Bearing 6204 轴承	8		For Double Wheel
36		0000-001482-00	Pin4×30 弹簧销	2		

010101 Frame Assembly 车架系统

Index		Part No.	Part Name	No.	Applied Date	Remark
37		1113-500020-10	Plate 线束封板	1	726150241-	For 560
37		1113-500020-00	Plate 线束封板	1	726150241-	For 685
38		0000-001741-00	Bushing 1618F 翻边轴套	6		
39		0000-001794-00	Round Pin ø4×30 弹簧销	2	726150341-	
40		1113-130009-00	Washer 加高转子	4	726170037-	
41		1113-130011-00	Sleeve 隔套	2	726170037-	

0102 Cover 外罩



0102 Cover 外罩


Index		Part No.	Part Name	No.	Applied Date	Remark
1	01	0000-001705-00	Screw M5×8 螺钉	8	-726180494	
	02	202800400001	Screw M5×8 螺钉	8	726180495-	
2		0000-001611-00	Screw M8×10 螺钉	6		
3		1113-142002-00	Right Hydraulic Cover 右液压罩	1		For Manual lowering
3		1113-142003-00	Right Hydraulic Cover 右液压罩	1		For Electric lowering
3		1113-142002-00-CK	Right Hydraulic Cover 右液压罩	1		For Manual lowering,CLARK green
3		1113-142003-00-CK	Right Hydraulic Cover 右液压罩	1		For Electric lowering,CLARK green
4	01	1113-141001-00	Driving Cover 驱动罩	1	-727190230	For small drive wheel
	02	1113-141002-0A	Driving Cover 驱动罩	1	727190231-	For small drive wheel, EP20190109-1
4	01	1113-141002-00	Driving Cover 驱动罩	1	-726219999	For big drive wheel
	02	1113-141002-0A	Driving Cover 驱动罩	1	727100000-	For big drive wheel
5		1113-142001-00	Left Hydraulic Cover 左液压罩	1		
5		1113-142001-00-CK	Left Hydraulic Cover 左液压罩	1		CLARK green

2000

Driving System

驱动系统

0201 Driving System 驱动系统




0201 Driving System 驱动系统

Index		Part No.	Part Name		No.	Applied Date	Remark
1	01	0000-001609-00	Screw M4×8	螺钉	3		Cancelled
	02	302018000001	Bolt M4×10	开槽带孔螺栓	3		
2		1113-210006-00	Cover	链轮罩	1		
3	01	1113-210200-00	Chain	链条	1	-727190230	
	02	1113-210200-0A	Chain	链条	1	727190231-	EP20190109-1
4		1113-210004-00	Chain Wheel	27齿链轮	1		
5		0000-001707-00	Screw M5×8	自锁螺钉	4		
6		1113-210003-00	Snap Ring	挡圈	1		
7		0000-001622-00	Flatwasher ø6	平垫	1		
8		0000-001613-00	Screw M6×12	螺钉	1		
9	01	1113-210100-00	Driving Wheel	驱动轮	1	-727190230	
	02	1113-210100-0A	Driving Wheel	驱动轮	1	727190231-	EP20190109-1
10	01	1113-210005-00	Shaft	轮轴	1	-727190230	
	02	1113-210005-0A	Shaft	轮轴	1	727190231-	EP20190109-1
11		0000-000020-00	Bearing6204	深沟球轴承	2		
12		0000-000740-00	Nut M8	螺母	1		
13		1113-211001-00	Chain Wheel	9齿链轮	1		
14		0000-001625-00	Bolt M8×25	螺栓	3		
15		0000-000210-00	Flatwasher ø8	大平垫	3		
16	01	1113-210002-00	Gear Case	轮架	1	-727190230	
	02	1113-210002-0A	Gear Case	轮架	1	727190231-	EP20190109-1
17	01	1113-211100-00	Motor	驱动电机	1	-727190230	
	02	1113-211100-0A	Motor	驱动电机	1	727190231-	EP20190109-1
18		0000-000660-00	Flat Key 5×18	平键	1		
19		0000-001623-00	Flat Key 8×40	平键	1		

0201 Driving System 驱动系统

Index		Part No.	Part Name		No.	Applied Date	Remark
20	01	1113-211200-00	Brake Assembly	制动器	1	-727190230	Without Manual Brake Release
	02	1113-211200-0A	Brake Assembly	制动器	1	727190231-	Without Manual Brake Release, EP20190109-1
20		1113-211200-10	Brake Assembly	制动器	1		Optional, With Manual Brake Release
21		0000-000701-00	Screw M4×10	螺钉	4		
22		0000-001231-00	Bearing6013	深沟球轴承	1		
23		0000-000159-00	Lockwasher ø8	弹垫	4		
24	01	1113-210001-00	Bridge	承载桥	1	-727190230	
	02	1113-220001-00	Bridge	承载桥	1	727190231-	EP20190109-1
25		0000-001230-00	Bearing51113	推力球轴承	1		
26	01	1113-210300-00	Bracket	手柄安装座	1	-726219999	
	02	1113-210300-0A	Bracket	手柄安装座	1	727100000-	
27		0000-000169-00	Screw M8×30	螺钉	4		
28		1113-300002-00	Spring	弹簧	1		
29		1113-302002-00	Spring Bearer	弹簧压板	1		
30		1113-302001-00	Spring Guidepost	弹簧导向柱	1		
31		1113-211000-00	Driving Assembly	驱动单元总成	1		
32		1113-500021-00	Electrostatic Chain	静电链条	1	726180208-	
33		0000-001577-00	Pin	销	1	726180208-	

0202 Driving System (Big driving wheel) 驱动系统 (大驱动)



0202Driving System (Big driving wheel) 驱动系统 (大驱动)

Index		Part No.	Part Name		No.	Applied Date	Remark
1		0000-001231-00	Bearing6013	深沟球轴承6013	1		
2		0000-000159-00	Lockwasher ø8	弹垫8	4		
3		1113-220001-00	Bridge	承载桥	1		
4		0000-001230-00	Bearing51113	推力球轴承51113	1		
5	01	1113-210300-00	Bracket	手柄安装座	1	-726219999	
	02	1113-210300-0A	Bracket	手柄安装座	1	727100000-	
6		0000-000169-00	Screw M8×30	螺钉 M8*20	4		
7		1113-300002-00	Spring	弹簧	1		
8	01	1113-221101-00	Gear Case	箱体	1	-727160691	EP2018090301
	02	1113-221101-0A	Gear Case	箱体	1	727160692-	
9	01	0000-000665-00	Screw M4×45	螺钉	3	-726190590	
	02	1115-240003-0A	Screw	螺钉	3	726190591-	
10		1115-200007-00	Cap	闷盖	1		
11		0000-000386-00	Scrw M6×20	螺钉	14		
12		0000-000056-00	Lockwasher ø6	弹垫	15		
13		0000-000013-00	Grease Fitting M8	直通式压注油杯	1		
14		0000-000704-00	Pin ø6×20	定位销	2		
15		1115-200001-00	Gear Cover	箱盖	1		
16		0000-000658-00	Snap Ring For Hole ø42	孔用弹性挡圈	1		
17		0000-000659-00	Snap Ring ø15	挡圈	2		
18		0000-000667-00	Bearing 61905Z	轴承	1		
19		1115-GSX-10	Gear Kit	齿轮修理包	1		The kit includes 2 gears (Pos.19)
20		0000-000680-00	Bearing 16003Z	轴承	1		
21		1115-GSX-20	Gear Kit	齿轮修理包	1		The kit includes 2 gears (Pos.21)
22		0000-000660-00	Key 5×5×18	平键	1		
23		0000-000026-00	Screw M8×30	螺钉	5		

0202 Driving System (Big drive wheel) 驱动系统 (大驱动)

Index		Part No.	Part Name	No.	Applied Date	Remark
24		0000-000159-00	Lockwasher ø8 弹垫	5		
25		0000-001788-00	Oil Seal ø155×173×10 骨架油封	1		
26	01	0000-000661-00	Screw M5×20 螺钉	12		replaced by #302001000091
	02	302001000091	Screw M5×25 螺钉	6		
27		0000-000206-00	Lockwasher ø5 弹垫	6		
28		0000-000662-00	Flat Key 5×5×12 平键	2		
29		0000-000671-00	Oil Seal ø16×28×7 骨架油封	1		
30		0000-000663-00	Bearing 61824-2RS 轴承	2		
31		1115-220000-A0	Driving Wheel 驱动轮	1		
32		1115-200010-00	Bearing Baffle 轴承挡板	1		
33		1115-250000-00	Motor 电机	1		
34		1115-240001-00	Brakelining 刹车片	1		
35	01	1115-520012-00	Brake Assembly 制动器总成	1	-726190590	
	02	1115-520012-0A	Brake Assembly 制动器总成	1	726190591-727160885	
	03	1115-520012-10	Brake Assembly 制动器总成	1	727160886-	EP20180910
36		1115-250001-00	Brush 碳刷	4		
37		0000-000004-00	Screw M5×12 螺钉	2		
38		1115-231000-00	Bracket 电机线安装座	1		
39		1115-250003-00	Holder Brush 碳刷架	1		
40		1115-250002-00	Brush Spring 碳刷弹簧	4		
41		1115-200001-A0	Inner rim 内轮圈	1		
42		1113-302002-00	Spring Bearer 弹簧压板	1		
43		1113-302001-00	Spring Guidepost 弹簧导向柱	1		
44		1113-221102-00	Bracket 护板	1	-726219999	cancelled
45	01	0000-001703-00	Screw M6×10 螺钉	1	-726210370	
	02	302018000002	Screw M6×10 螺钉	1	726210371-	
46		1113-221000-00	Driving Assembly 驱动单元总成	1		

0202 Driving System (Big drive wheel) 驱动系统 (大驱动)


Index		Part No.	Part Name	No.	Applied Date	Remark
47		1113-500021-0A	Electrostatic Chain 静电链条	1	726180208-	
48		1115-240002-0A	Scraper Seal 防尘圈	1	726190591-	
49		0000-000380-00	Flatwasher ø6 平垫	1	726210371-	
50		0000-001577-00	Pin 销	1	726210371-	
51		1113-221103-00	Block 限位块	1	-727160691	
52		302001000032	Screw M10×16 内六角圆柱头螺钉	1	-727160691	
53		302003000005	Screw M6×20 内六角沉头螺钉	2	-727160691	
54		304003000006	Lockwasher ø10 弹垫	1	-727160691	
55		1113-520022-00	Line 转接线	1	727160886-	EP20180910

3000

Operating Control System

操作系统

0301 operating grip (Manual lowering) 操作杆 (手动下降)




0301 operating grip (Manual lowering) 操作杆 (手动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1113-301000-00	Control Pod Assembly 手柄头总成	1		Without Upright walking
1		1113-302100-00	Control Pod Assembly 手柄头总成	1	726190265-	Option,With Upright walking
2		0000-001029-00	Screw M4×12 螺钉	2		
3		1113-313000-00	Knob 拉手	1		
4	01	0000-001706-00	Bushing2005 翻边自润滑轴承	2	-726219999	
	02	202801900035	Bushing2010F 翻边自润滑轴承	2	727100000-	
5		1113-300003-00	Shaft 手柄安装轴	1		
6		0000-001023-00	Pinc4x35 弹簧销	1		
7		1113-300001-00	Bumper Block 缓冲块	1		
8	01	1113-312000-00	Control Handle 手柄方管	1	-726219999	
	02	1113-312000-0A	Control Handle 手柄方管	1	727100000-	
9	01	1121-300002-00	Shaft 压轮轴	1	-726219999	
	02	1121-300002-0A	Shaft 压轮轴	1	727100000-	Replaced by1113-300007-00
	03	1113-300007-00	Shaft 压轮轴	1		EP20190109-2
10		0000-001233-10	Pinc4x20 弹簧销	1	-726219999	
11	01	1121-300003-00	Roller 压轮	1		Replaced by1113-300006-00
	02	1113-300006-00	Roller 压轮	1		EP20190109-2
12		0000-001235-10	Pinc6x30 弹簧销	1		
13		0000-001236-10	Pinc4x12 弹簧销	2		
14		0000-001707-00	Screw M5x8 螺钉	2		
15		1113-500011-00	Inductor I 感应片	1		
16	01	1113-314002-00	Steel Wire 拉线	1	-726190006	
	02	1113-314002-0A	Steel Wire 拉线	1	726190007-	
17		1113-314003-00	Bracket 拉线支板	1		
18		0000-001703-00	Screw M6x10 螺钉	4		

0301 operating grip (Manual lowering) 操作杆 (手动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
19		0000-000122-00	Lockwasher ø4 弹垫	2		
20	01	1113-314004-00	Steel Wire 拉线	1	-726190006	
	02	1113-314004-0A	Steel Wire 拉线	1	726190007-	
21	01	1113-315000-00	Bracket 铰接座	1	-726219999	
	02	1113-315000-0A	Bracket 铰接座	1	727100000-	
22		1113-314005-0A	Steel Wire Head 拉线头	1	726190007-	
23		202801900014	Bushing1512 自润滑轴承	1	727100000-	
24		202801900023	Bushing1514 自润滑轴承	1	727100000-	
25		0000-000416-00	Screw M4x8 沉头内六角螺钉	1		
26		0000-001103-00	Harness Clamp 线夹	1		


0302 Handle head assembly (Manual lowering) 手柄头总成 (手动下降)



0302 Handle head assembly (Manual lowering) 手柄头总成 (手动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1113-301003-00	Left Switch 左旋钮	1		
2		1113-520005-00	Lifting And Horn Wire 喇叭起升线束	1		
3		1113-301006-00	Spring 弹簧	1		
4		0000-001630-00	Screw M3 × 5 螺钉	4		
5		1113-301100-00	Meter 仪表	1		
6		1113-301200-00	Accelerator 加速器	1		
7		1113-520013-00	Reverse Wire 紧急反向按钮线束	1		
8		1113-301004-00	Cap 上盖	1		
9		1113-301005-00	Cover 下盖	1		
10		1113-301002-00	Button Reverse Cover 反向板	1		
11		1113-301001-00	Right Switch 右旋钮	1		
12		0000-001722-00	Screw M3 × 12 螺钉	2		
13		0000-000665-00	Screw M4×45 螺钉	2		
14		0000-001031-00	Screw M4×30 螺钉	2		
15		1113-301007-00	Plate 垫块	1		
16		1121-522000-00	Button 按钮	3		
17		1113-520020-00	Upright Walking Harness 直立行走按钮线束	1	726190265-	Option


0303 operating grip (Electric lowering) 操作手柄杆 (电动下降)



0303 operating grip (Electric lowering) 操作杆 (电动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1113-302000-00	Control Pod Assembly 手柄头总成	1		
2		0000-001029-00	Screw M4×12 螺钉	2		
3		0000-001703-00	Screw M6×10 螺钉	4		
4	01	0000-001706-00	Bushing2005 自润滑轴承	2	-726219999	
	02	202801900035	Bushing2010F 翻边自润滑轴承	2	727100000-	
5		1113-300003-00	Shaft 手柄安装轴	1		
6		0000-001023-00	Pinc4x35 弹簧销	1		
7		1113-300001-00	Bumper Block 缓冲块	1		
8	01	1113-312000-00	Control Handle 手柄方管	1	-726219999	
	02	1113-312000-0A	Control Handle 手柄方管	1	727100000-	
9	01	1121-300002-00	Shaft 压轮轴	1	-726219999	
	02	1121-300002-0A	Shaft 压轮轴	1	727100000-	Replaced by1113-300007-00
	03	1113-300007-00	Shaft 压轮轴	1		EP20190109-2
10		0000-001233-10	Pinc4x20 弹簧销	1	-726219999	
11	01	1121-300003-00	Roller 压轮	1		Replaced by1113-300006-00
	02	1113-300006-00	Roller 压轮	1		EP20190109-2
12		0000-001707-00	Screw M5x8 螺钉	2		
13		1113-500011-00	Inductor I 感应片	1		
14		1113-314003-00	Bracket 拉线支板	1		
15	01	1113-315000-00	Bracket 铰接座	1	-726219999	
	02	1113-315000-0A	Bracket 铰接座	1	727100000-	
16		0000-000122-00	Lockwasher ø4 弹垫	2		
17		202801900014	Bushing1512 自润滑轴承	1	727100000-	
18		202801900023	Bushing1514 自润滑轴承	1	727100000-	

0304 Handle head assembly (Electric lowering) 手柄头总成 (电动下降)



0304 Handle head assembly (Electric lowering) 手柄头总成 (电动下降)


Index		Part No.	Part Name	No.	Applied Date	Remark
1		1113-520020-00	Lowering Wire 下降线束	1		
2		1113-520005-00	Lifting And Horn Wire 喇叭起升线束	1		
3		1113-301006-00	Spring 弹簧	1		
4		0000-001630-00	Screw M3× 5 螺钉	3		
5		1113-301100-00	Meter 仪表	1		
6		1113-301200-00	Accelerator 加速器	1		
7		1113-520013-00	Reversing Switch 紧急反向按钮线束	1		
8		1113-301004-00	Cap 上盖	1		
9		1113-301005-00	Cover 下盖	1		
10		1113-301002-00	Button Reverse Cover 反向板	1		
11		1113-301001-00	Right Switch 右旋钮	1		
12		0000-001722-00	Screw M3×12 螺钉	2		
13		1113-301003-00	Left Switch 左旋钮	1		
14		0000-000665-00	Screw M4×45 螺钉	2		
15		0000-001031-00	Screw M4×30 螺钉	2		
16		1113-301007-00	Plate 垫块	1		
17		1121-522000-00	Button 按钮	4		

4000

Hydraulic System

液压系统

0401 Hydraulic System (Manual lowering) 液压系统 (手动下降)




0401 Hydraulic System (Manual lowering) 液压系统 (手动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1121-410001-00	Steel Ball 钢球	1		
2		1113-500015-00	Switch the plate 开关安装板	1		
3		0000-000973-00	Packing32×42×6 密封圈	1		
4		1113-411002-00	Snap Ring 42×32×2 挡圈	1		
5		0000-000978-00	Ring Wiper32×40×5/6.5 防尘圈	1		
6		1113-413100-00	Piston Rod 活塞杆	1		For small drive wheel
6		1113-413100-20	Piston Rod 活塞杆	1		For big drive wheel
7		1113-421000-00	Check Valve 节流阀	1		
8		1113-422000-00	Manual Valve 手动阀	1		
9		1113-423000-00	Safety Valve 安全阀	1		
10		0000-001577-00	Pinc1.6x32 销	1		
11		0000-001257-00	B-Shaftc6x35 销轴 B 型	1		
12		1113-400001-00	Plate 下降顶板	1		
13		1113-430001-00	Plate 底板	1	-726140004	
14		1113-430004-00	Sealing Ring 密封垫	1	-726140004	
15		1113-436000-00	Pump 齿轮泵	1		
16		1113-411003-20	Cylinder 缸体	1		
17		1113-431000-10	Oil pipe 油管	1		
18		0000-001624-00	O-Ring17×1.5 O 型圈	1		
19		1113-300005-00	Spring 弹簧	1		
20		0000-000044-00	Flatwasher ø14 平垫	1		
21		1113-433000-00	Motor 电机	1		
22		0000-001632-00	Screw5 x63 螺钉	4		
23		2701-121200-00	Connector 接头	1		
24		0000-001626-00	Screw4 x14 螺钉	8	-726140004	

0401 Hydraulic System (Manual lowering) 液压系统 (手动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
25		2302-141300-10	Choke Plug 堵头	1		
26		0000-001618-00	Screw M3×6 螺钉	4		
27		1113-500003-00	ReedSwitchMagnet 干簧管磁铁	1		
28		1113-500010-00	Reed Switch Plate 干簧管安装板	1		
29		0000-001613-00	Bolt M6×12 螺栓	3		
30		0000-001627-00	Bolt M8×20 螺栓	4		
31		1113-500001-00	Reed Switch 干簧管	1		
32		0000-001010-01	Screw M4x8 螺钉	2		
33		1113-411000-00	Cylinder 油缸	1		For small drive wheel
33		1113-411000-20	Cylinder 油缸	1		For big drive wheel
34		1113-500006-00	Contactactor 接触器	1		
35		0000-001702-00	Screw M3×8 螺钉	2		
36		1113-431000-00	Pump 泵壳体	1	-726140004	
37		1113-430003-00	Plate II 安装板 II	1		
38		0000-000616-00	Screw M5×10 螺钉	1		
KIT		1113-ZZG-0A	Seal Kit (Includes 3, 5) 油缸修理包	1		

040101 Hydraulic System (Manual lowering) 液压系统 (手动下降)




040101 Hydraulic System (Manual lowering) 液压系统 (手动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1121-410001-00	Steel Ball 钢球	1		
2		1113-500015-00	Switch the plate 开关安装板	1	-726219999	canceled
3		0000-000973-00	Packing32×42×6 密封圈	1		
4		1113-411002-00	Snap Ring 42×32×2 挡圈	1		
5		0000-000978-00	Ring Wiper32×40×5/6.5 防尘圈	1		
6		1113-413100-00	Piston Rod 活塞杆	1		For small drive wheel
6		1113-413100-20	Piston Rod 活塞杆	1		For big drive wheel
7		1113-421000-00	Check Valve 节流阀	1		
8		1113-422000-00	Manual Valve 手动阀	1		
9		1113-423000-00	Safety Valve 安全阀	1		
10		0000-001577-00	Pinc1.6x32 销	1		
11		0000-001257-00	B-Shaftc6x35 销轴 B 型	1		
12		1113-400001-00	Plate 下降顶板	1		
13		1113-430005-00	Plate 底板	1	726140005-	
14		1113-430006-00	Sealing Ring 密封圈	1	726140005-	
15		1113-436000-00	Pump 齿轮泵	1		
16		1113-411003-20	Cylinder 缸体	1		
17		1113-431000-10	Oil pipe 油管	1		
18		0000-001624-00	O-Ring17×1.5 O 型圈	1		
19		1113-300005-00	Spring 弹簧	1		
20		0000-000044-00	Flatwasher ø14 平垫	1		
21		1113-433000-00	Motor 电机	1		
22		0000-001632-00	Screw5 x63 螺钉	4		
23		2701-121200-00	Connector 接头	1		
24		0000-001031-00	Screw4 x30 螺钉	4	726140005-	

040101 Hydraulic System (Manual lowering) 液压系统 (手动下降)

Index	Part No.	Part Name	No.	Applied Date	Remark
25		2302-141300-10 Choke Plug 堵头	1		
26		0000-001618-00 Screw M3×6 螺钉	4	-726219999	canceled
27		1113-500003-00 ReedSwitchMagnet 干簧管磁铁	1	-726219999	canceled
28		1113-500010-00 Reed Switch Plate 干簧管安装板	1	-726219999	canceled
29		0000-001613-00 Bolt M6×12 螺栓	3		
30		0000-001627-00 Bolt M8×20 螺栓	4	-726219999	canceled
31		1113-500001-00 Reed Switch 干簧管	1	-726219999	canceled
32		0000-001010-01 Screw M4x8 螺钉	2		
33		1113-411000-00 Cylinder 油缸	1		For small drive wheel
33		1113-411000-20 Cylinder 油缸	1		For big drive wheel
34	01	1113-500006-00 Contactor 接触器	1	-726120108	Repalced by the part #1113-500006-10 and the part #1113-430003-00
	02	1113-500006-10 Contactor 接触器	1	726120109-	
35	01	0000-001702-00 Screw M3×8 螺钉	2	-726120108	
	02	0000-001609-00 Screw M4×8 螺钉	2	726120109-	
36		1113-434000-00 Valve Body 泵壳体	1	726140005-	
37		1113-430003-00 Plate II 安装板 II	1		
38		0000-000616-00 Screw M5×10 螺钉	1		
39		0000-000122-00 Lockwasher ø4 弹垫	4	726140005-	
40		1113-430007-00 Magnet 磁铁	1	726140005-	
41		0000-001674-00 Washer ø12 组合垫圈	1		
KIT		1113-ZZG-0A Seal Kit (Includes 3, 5) 油缸修理包	1		

040102 Hydraulic System (Manual lowering) 液压系统 (手动下降)




040102 Hydraulic System (Manual lowering) 液压系统 (手动下降)

Index		Part No.	Part Name		No.	Applied Date	Remark
1		1121-410001-00	Steel Ball	钢球	1		
2		1113-502000-0A	Interlock Switch	互锁开关	1	727100000-	
3		0000-000973-00	Packing32×42×6	密封圈	1		
4		1113-411002-00	Snap Ring 42×32×2	挡圈	1		
5		0000-000978-00	Ring Wiper32×40×5/6.5	防尘圈	1		
6	01	1113-413100-00	Piston Rod	活塞杆	1	-727190230	For small drive wheel
	02	1113-413100-20	Piston Rod	活塞杆	1	727190231-	For small drive wheel, EP20190109-1
6		1113-413100-20	Piston Rod	活塞杆	1		For big drive wheel
7		1113-421000-00	Check Valve	节流阀	1		
8		1113-422000-00	Manual Valve	手动阀	1		
9		1113-423000-00	Safety Valve	安全阀	1		
10		0000-001577-00	Pinc1.6x32	销	1		
11		0000-001257-00	B-Shaftc6x35	销轴 B 型	1		
12		1113-400001-00	Plate	下降顶板	1		
13		1113-430005-00	Plate	底板	1	726140005-	
14		1113-430006-00	Sealing Ring	密封圈	1	726140005-	
15		1113-436000-00	Pump	齿轮泵	1		
16		1113-411003-20	Cylinder	缸体	1		
17		1113-431000-10	Oil pipe	油管	1		
18		0000-001624-00	O-Ring17×1.5	O 型圈	1		
19		1113-300005-00	Spring	弹簧	1		
20		0000-000044-00	Flatwasher ø14	平垫	1		
21		1113-433000-00	Motor	电机	1		
22		0000-001632-00	Screw5 x63	螺钉	4		
23		2701-121200-00	Connector	接头	1		
24		0000-001031-00	Screw4 x30	螺钉	4	726140005-	

040102 Hydraulic System (Manual lowering) 液压系统 (手动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
25		2302-141300-10	Choke Plug 堵头	1		
26		0000-001674-00	Washer ø12 组合垫圈	1		
27		1113-430007-00	Magnet 磁铁	1	726140005-	
28		0000-000122-00	Lockwasher ø4 弹垫	4	726140005-	
29		0000-001613-00	Bolt M6×12 螺栓	3		
30		0000-001627-00	Bolt M8×20 螺栓	4		
31		0000-000616-00	Screw M5×10 螺钉	5		
32		1113-430003-00	Plate II 安装板 II	1		
33	01	1113-411000-00	Cylinder 油缸	1	-727190230	For small drive wheel
	02	1113-411000-20	Cylinder 油缸	1	727190231-	For small drive wheel. EP20190109-1
33		1113-411000-20	Cylinder 油缸	1		For big drive wheel
34	01	1113-500006-00	Contactactor 接触器	1	-726120108	Repalced by the part #1113-500006-10 and the part #1113-430003-00
	02	1113-500006-10	Contactactor 接触器	1	726120109-	
35	01	0000-001702-00	Screw M3×8 螺钉	2	-726120108	
	02	0000-001609-00	Screw M4×8 螺钉	2	726120109-	
36		1113-434000-00	Valve Body 泵壳体	1	726140005-	
37		1113-500022-0A	Protective Ring 护线圈	1	726200097-	
38		1113-430002-00	Plate 固定板 I	1	726200097-	
39		1113-430000-00	Pump & Motor Assembly 液压站总成	1		
KIT		1113-ZZG-0A	Seal Kit (Includes 3, 5) 油缸修理包	1		

0402 Hydraulic System (Electric lowering) 液压系统 (电动下降)




0402 Hydraulic System (Electric lowering) 液压系统 (电动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1121-410001-00	Steel Ball 钢球	1		
2		1113-500015-00	Switch the plate 开关安装板	1		
3		0000-000973-00	Packing32×42×6 密封圈	1		
4		1113-411002-00	Snap Ring 42×32×2 挡圈	1		
5		0000-000978-00	Ring Wiper32×40×5/6.5 防尘圈	1		
6		1113-413100-00	Piston Rod 活塞杆	1		For small drive wheel
6		1113-413100-20	Piston Rod 活塞杆	1		For big drive wheel
7		1113-421000-10	Check Valve 节流阀	1		
8		1113-422000-10	Safety Valve 安全阀	1		
9		1113-423000-10	Solenoid Valve 电磁阀	1		
10		0000-001632-00	Screw5×63 螺钉	4		
11		0000-001624-00	O-Ring17×1.5 O 型圈	1		
12		1113-432000-00	Pump 泵壳体	1	-726140004	
13		1113-411003-20	Cylinder 缸体	1		
14		1113-430001-00	Plate 底板	1	-726140004	
15		1113-430004-00	Sealing Ring 密封垫	1	-726140004	
16		1113-436000-00	Pump 齿轮泵	1		
17		2302-141300-10	Choke Plug 堵头	1		
18		0000-001618-00	Screw M3*6 螺钉	4		
19		1113-431000-10	Oil Pipe 油管	1		
20		0000-000044-00	washer Ø14 组合垫	1		
21		1113-433000-00	Motor 电机	1		
22		2701-121200-00	Connector 接头	1		
23		0000-001626-00	Screw M4×14 螺钉	8	-726140004	
24		1113-500003-00	ReedSwitchMagnet 干簧管磁铁	1		

0402 Hydraulic System (Electric lowering) 液压系统 (电动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
25		1113-500010-00	Reed Switch Plate 干簧管安装板	1		
26		0000-001613-00	Bolt M6×12 螺栓	3		
27		0000-001627-00	Bolt M8×20 螺栓	4		
28		1113-500001-00	Reed Switch 干簧管	1		
29		0000-001010-01	Screw M4×8 螺钉	2		
30		1113-411000-00	Cylinder 油缸	1		For small drive wheel
30		1113-411000-20	Cylinder 油缸	1		For big drive wheel
31		1113-500006-00	Contactactor 接触器	1		
32		0000-001702-00	Screw M3×8 螺钉	2		
33		1113-430003-00	Plate II 安装板 II	1		
34		0000-000616-00	Screw M5×10 螺钉	1		
KIT		1113-ZZG-0A	Seal Kit (Includes 3, 5) 油缸修理包	1		

040201 Hydraulic System (Electric lowering) 液压系统 (电动下降)




040201 Hydraulic System (Electric lowering) 液压系统 (电动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1121-410001-00	Steel Ball 钢球	1		
2		1113-500015-00	Switch the plate 开关安装板	1	-726219999	canceled
3		0000-000973-00	Packing32×42×6 密封圈	1		
4		1113-411002-00	Snap Ring 42×32×2 挡圈	1		
5		0000-000978-00	Ring Wiper32×40×5/6.5 防尘圈	1		
6		1113-413100-00	Piston Rod 活塞杆	1		For small drive wheel
6		1113-413100-20	Piston Rod 活塞杆	1		For big drive wheel
7		1113-421000-10	Check Valve 节流阀	1		
8		1113-422000-10	Safety Valve 安全阀	1		
9		1113-423000-10	Solenoid Valve 电磁阀	1		
10		0000-001632-00	Screw5×63 螺钉	4		
11		0000-001624-00	O-Ring17×1.5 O 型圈	1		
12		1113-435000-00	Pump 泵壳体	1	726140005-	
13		1113-411003-20	Cylinder 缸体	1		
14		1113-430005-00	Plate 底板	1	726140005-	
15		1113-430006-00	Sealing Ring 密封圈	1	726140005-	
16		1113-436000-00	Pump 齿轮泵	1		
17		2302-141300-10	Choke Plug 堵头	1		
18		0000-001618-00	Screw M3*6 螺钉	4	-726219999	canceled
19		1113-431000-10	Oil Pipe 油管	1		
20		0000-000044-00	washer ø14 组合垫	1		
21		1113-433000-00	Motor 电机	1		
22		2701-121200-00	Connector 接头	1		
23		0000-001031-00	Screw4 x30 螺钉	4	726140005-	
24		1113-500003-00	ReedSwitchMagnet 干簧管磁铁	1	-726219999	canceled

040201 Hydraulic System (Electric lowering) 液压系统 (电动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
25		1113-500010-00	Reed Switch Plate 干簧管安装板	1	-726219999	canceled
26		0000-001613-00	Bolt M6×12 螺栓	3		
27		0000-001627-00	Bolt M8×20 螺栓	4		
28		1113-500001-00	Reed Switch 干簧管	1	-726219999	canceled
29		0000-001010-01	Screw M4×8 螺钉	2	-726219999	canceled
30		1113-411000-00	Cylinder 油缸	1		For small drive wheel
30		1113-411000-20	Cylinder 油缸	1		For big drive wheel
31	01	1113-500006-00	Contactor 接触器	1	-726120108	Repalced by the part #1113-500006-10 and the part #1113-430003-00
	02	1113-500006-10	Contactor 接触器	1	726120109-	
32	01	0000-001702-00	Screw M3×8 螺钉	2	-726120108	
	02	0000-001609-00	Screw M4×8 螺钉	2	726120109-	
33		1113-430003-00	Plate II 安装板 II	1		
34		0000-000616-00	Screw M5×10 螺钉	1		
35		0000-000122-00	Lockwasher ø4 弹垫	4	726140005-	
36		1113-430007-00	Magnet 磁铁	1	726140005-	
37		0000-001674-00	Washer ø12 组合垫圈	1		
KIT		1113-ZZG-0A	Seal Kit (Includes 3, 5) 油缸修理包	1		

040202 Hydraulic System (Electric lowering) 液压系统 (电动下降)



040202 Hydraulic System (Electric lowering) 液压系统 (电动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1121-410001-00	Steel Ball 钢球	1		
2		1113-502000-0A	Interlock Switch 互锁开关	1	727100000-	
3		0000-000973-00	Packing32×42×6 密封圈	1		
4		1113-411002-00	Snap Ring 42×32×2 挡圈	1		
5		0000-000978-00	Ring Wiper32×40×5/6.5 防尘圈	1		
6	01	1113-413100-00	Piston Rod 活塞杆	1	-727190230	For small drive wheel
	02	1113-413100-20	Piston Rod 活塞杆	1	727190231-	For small drive wheel, EP20190109-1
6		1113-413100-20	Piston Rod 活塞杆	1		For big drive wheel
7		1113-421000-10	Check Valve 节流阀	1		
8		1113-422000-10	Safety Valve 安全阀	1		
9		1113-423000-10	Solenoid Valve 电磁阀	1		
10		0000-001632-00	Screw5×63 螺钉	4		
11		0000-001624-00	O-Ring17×1.5 O 型圈	1		
12		1113-435000-00	Pump 泵壳体	1	726140005-	
13		1113-411003-20	Cylinder 缸体	1		
14		1113-430005-00	Plate 底板	1	726140005-	
15		1113-430006-00	Sealing Ring 密封圈	1	726140005-	
16		1113-436000-00	Pump 齿轮泵	1		
17		2302-141300-10	Choke Plug 堵头	1		
18		0000-001674-00	Washer ø12 组合垫圈	1		
19		1113-431000-10	Oil Pipe 油管	1		
20		0000-000044-00	washer ø14 组合垫	1		
21		1113-433000-00	Motor 电机	1		
22		2701-121200-00	Connector 接头	1		
23		0000-001031-00	Screw4 x30 螺钉	4	726140005-	
24		1113-430007-00	Magnet 磁铁	1	726140005-	

040202 Hydraulic System (Electric lowering) 液压系统 (电动下降)

Index		Part No.	Part Name	No.	Applied Date	Remark
25		0000-000122-00	Lockwasher ø4 弹垫	4	726140005-	
26		0000-001613-00	Bolt M6×12 螺栓	3		
27		0000-001627-00	Bolt M8×20 螺栓	4		
28		0000-000616-00	Screw M5×10 螺钉	3		
29		1113-430003-00	Plate II 安装板 II	1		
30	01	1113-411000-00	Cylinder 油缸	1	-727190230	For small drive wheel
	02	1113-411000-20	Cylinder 油缸	1	727190231-	For small drive wheel, EP20190109-1
30		1113-411000-20	Cylinder 油缸	1		For big drive wheel
31	01	1113-500006-00	Contactactor 接触器	1	-726120108	Repalced by the part #1113-500006-10 and the part #1113-430003-00
	02	1113-500006-10	Contactactor 接触器	1	726120109-	
32	01	0000-001702-00	Screw M3×8 螺钉	2	-726120108	
	02	0000-001609-00	Screw M4×8 螺钉	2	726120109-	
33		1113-500022-0A	Protective Ring 护线圈	1	726200097-	
34		1113-430002-00	Plate 固定板 I	1	726200097-	
35		1113-430000-E0	Pump & Motor Assembly 液压站总成	1		
KIT		1113-ZZG-0A	Seal Kit (Includes 3, 5) 油缸修理包	1		


5000

Electrical System



电气系统

0501 Electrical Assembly 电气总成

Battery Section



Cradle Section




0501 Electrical Assembly 电气总成

Index	Part No.	Part Name	No.	Applied Date	Remark
1		0000-001610-00 Screw M5×10 螺钉	6		
2		0000-001609-00 Screw M4×8 螺钉	3		
3		0000-001619-00 Screw M5×25 螺钉	2		
4		1113-500003-00 Reed Switch Magnet 干簧管磁铁	1		
5		0000-001618-00 Screw M3×6 螺钉	2		
6		1113-500014-00 Bracket 干簧管安装板	1		
7	01	1113-540000-00 Switch Assembly 钥匙开关总成	1	-726170114	
	02	1113-540200-0A Switch Base 开关座	1	726170115-	
8	01	1113-500009-00 Key 钥匙	1	-726170114	
	02	1113-540100-0A Key 钥匙	1	726170115-	
9		1113-500008-00-10 Controller 控制器	1		For small drive wheel
9		1113-500008-00-50 Controller 控制器	1		For big drive wheel
10		0000-000614-00 Screw M4×10 螺钉	1		
11	01	1113-513000-00 Battery Pack 电池	1	-727130506	20Ah
	02	1113-513000-0B Battery Pack 电池	1	727130507-	20Ah
11		1113-513000-0A Battery 电池	1		26Ah
12		1113-511003-00 Bracket 电源公头座	1		Cancelled, EP20190109-3
13	01	1113-511007-00 Needle HSB-35A 插针	2	-726200096	
	02	1113-511007-0A Needle HSB-35A 插针	2	726200097-	Cancelled, EP20190109-3
14		1113-511002-00 Splint 电池夹板	2		
15		0000-001342-00 Screw M3×16 螺钉	8		
16		1113-511005-00 Bracket 信号线公头座	1		Cancelled, EP20190109-4
17		1113-511001-00 Bracket 电池底座	1		
18		3218-604000-00 Fetch-up Switch 急停开关	1		
19		1113-511004-00 Clamping Piece 夹片	1		
20	01	1113-511006-00 Needle HE 针	4	-726200096	
	02	1113-511006-0A Needle HE 针	4	726200097-	Cancelled, EP20190109-4

0501 Electrical Assembly 电气总成

Index		Part No.	Part Name		No.	Applied Date	Remark
21		1113-513002-00	Hole	HSB-35A 孔	2		Cancelled, EP20190109-5
22		1113-513003-00	Bracket	电源母头座	1		Cancelled, EP20190109-5
23		1113-513001-00	Hole	HE 孔	4		Cancelled, EP20190109-6
24		1113-513004-00	Bracket	信号线母头座	1		Cancelled, EP20190109-6
25		0000-001616-00	Screw M3×10	螺钉	8		Cancelled, EP20190109-4
26		0000-001631-00	Screw M3×14	螺钉	8		
27		0000-001617-00	Screw M4×10	螺钉	4		Cancelled, EP20190109-3
28		1113-500001-00	Reed Switch	干簧管	1		
29		1113-540000-0A	Switch Assembly	钥匙开关总成	1	726170115-	Includes 7,8
30		1113-511009-0A	Spring	HE 插针鼓簧	4		Cancelled, EP20190109-4
31		1113-511008-0A	Spring	插针鼓簧	2		Cancelled, EP20190109-3
32		LB00-00000Z-02	Bracket Assembly	电源母头座总成	1		EP20190109-5
33		LB00-00000Z-01	Bracket Assembly	信号线母头座总成	1		EP20190109-6
34		1113-511011-00	Bracket Assembly	电源公头座总成	1		EP20190109-3
35		1113-511010-00	Bracket Assembly	信号线公头座总成	1		EP20190109-4


0502 Wiring Harness 线束



0502 Wiring Harness 线束

Index		Part No.	Part Name	No.	Applied Date	Remark
1	01	1113-520001-00	Controller Wire 主线束	1		Replaced by #1113-520001-0B
	02	1113-520001-0B	Controller Wire 主线束	1	-726190264	
2		1113-520014-00	Power Connection Wire 电源电池通讯转接线	1		
3		1113-520004-00	Bend Wire 弯管线束	1		
4		1113-520010-00	Power Connection Wire 电源通讯连接线	1		
5		1113-520006-00	Horn 喇叭	1		
6		1113-520012-00	Wire 急停开关线束	1		
7		1113-530005-00	Wire M1 M1线	1		For big drive wheel
8		1113-530006-00	Wire M2 M2线	1		For big drive wheel
9		1113-520025-00	Fuse 5A 保险丝	1		


050201 Wiring Harness 线束



050201 Wiring Harness 线束

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1113-520001-10	Controller Wire 主线束	1	726190265-	
2		1113-520014-00	Power Connection Wire 电源电池通讯转接线	1		
3		1113-520004-00	Bend Wire 弯管线束	1		
4		1113-520010-00	Power Connection Wire 电源通讯连接线	1		
5		1113-520006-00	Horn 喇叭	1		
6		1113-520012-00	Wire 急停开关线束	1		
7		1113-530005-00	Wire M1 M1线	1		For big drive wheel
8		1113-530006-00	Wire M2 M2线	1		For big drive wheel
9		1113-520025-00	Fuse 5A 保险丝	1		


0503 Cable Assembly 电缆



0503 Cable Assembly 电缆了

Index		Part No.	Part Name	No.	Applied Date	Remark
1		1113-530001-00	Power cable- 电缆电源负线	1		
2		1113-530002-00	Power cable+ 电缆电源正线	1		
3		1113-530004-00	Controller- 控制器负极线	1		
4		1113-530003-00	Controller+ 控制器正极线	1		

0504 Charger Assembly 充电器总成



0504Charger Assembly 充电器总成

Index	Part No.	Part Name	No.	Applied Date	Remark
0		1113-512000-00 Charger Assembly 充电器总成	1		
1		1113-512200-00 Charger 充电器	1		
2	01	1115-500006-10 Charger Cable USA 充电线	1		For USA, Replaced by1113-500007-10
	02	1113-500007-10 Charger Cable USA 充电线	1		For USA, EP20190109-2
2	01	1115-500006-20 Charger Cable AUS 充电线	1		For AUS, Replaced by1113-500007-20
	02	1113-500007-20 Charger Cable AUS 充电线	1		For AUS, EP20190109-2
2	01	1115-500006-00 Charger Cable EUROPE 充电线	1		For EUROPE, , Replaced by1113-500007-00
	02	1113-500007-00 Charger Cable EUROPE 充电线	1		For EUROPE, EP20190109-2
2	01	1115-500006-40 Charger Cable JAPAN 充电线	1		For JAPAN, Replaced by1113-500007-40
	02	1113-500007-40 Charger Cable JAPAN 充电线	1		For JAPAN, EP20190109-2
2	01	1115-500006-50 Charger Cable CHINA 充电线	1		For CHINA, Replaced by1113-500007-50
	02	1113-500007-50 Charger Cable CHINA 充电线	1		For CHINA, EP20190109-2
2	01	1115-500006-30 Charger Cable END 充电线	1		For END, Replaced by1113-500007-30
	02	1113-500007-30 Charger Cable END 充电线	1		For END, EP20190109-2
2	01	1115-500006-60 Charger Cable CH 充电线	1		For CH, Replaced by1113-500007-60
	02	1113-500007-60 Charger Cable CH 充电线	1		For CH, EP20190109-2
3	01	1113-512100-00 Charger Bracket 充电器底座	1	-726211392	
	02	1113-512100-0A Charger Bracket 充电器底座	1	726211393-	
4		1113-511001-00 Bracket 电池底座	1		
5		0000-001610-00 Screw M5×10 螺钉	4		
6		0000-001342-00 Screw M3×16 螺钉	4		
7		1113-511005-00 Bracket 信号线公头座	1		Cancelled, EP20190109-4
8	01	1113-511006-00 Needle HE 针	4	-726200096	
	02	1113-511006-0A Needle HE 针	4	726200097-	Cancelled, EP20190109-4
9		0000-001616-00 Screw M3×10 螺钉	4		Cancelled, EP20190109-4
10		0000-000982-00 Nut M3 螺母	8		

0504Charger Assembly 充电器总成

Index	Part No.	Part Name	No.	Applied Date	Remark
11		0000-001617-00 Screw M4×10 螺钉	2		Cancelled, EP20190109-3
12		1113-511003-00 Bracket 电源公头座	1		Cancelled, EP20190109-3
13	01	1113-511007-00 Needle HSB-35A 插针	2	-726200096	
	02	1113-511007-0A Needle HSB-35A 插针	2	726200097-	Cancelled, EP20190109-3
14		0000-001705-00 Screw M5×8 螺钉	4		
15		1113-520017-00 Charging Short Wires 充电短接线	1		
16		1113-511009-0A Spring HE 插针鼓簧	4		Cancelled, EP20190109-4
17		1113-511008-0A Spring 插针鼓簧	2		Cancelled, EP20190109-3
18		1113-511011-00 Bracket Assembly 电源公头座总成	1		EP20190109-3
19		1113-511010-00 Bracket Assembly 信号线公头座总成	1		EP20190109-4